

Target Module Connection and Disconnection Procedure		
Document-141576	Release No. 3	Release Date.: 2019-10-23

6 Module Connection Checklist

SEQ	ITEM	NOTE	CHECK
Safety	Acknowledge and Activate Work Permit	Call ISAC operators (x7500) Call Main Control Room if disconnecting or closing water supply/return in SEQ 0 (x7333) or if supplied airhood is necessary	✓
Safety	Hold Pre-Job Briefing	<ul style="list-style-type: none"> • Discuss hazards, safety protocols and work steps listed in this document and checklists. • All workers on the work permit shall be present. If there are concerns about the job, discuss with supervisors and re-plan if necessary. • If you become contaminated during the job, contact the Main Control Room at x7333 for assistance. 	✓
Safety	<ul style="list-style-type: none"> ✓• Electronic Dosimeter ✓• Tank Suit ✓• Respirator/Supplied Air ✓• Overshoes (double) ✓• Gloves(double) ✓• Safety Glasses / Full Face Respirator 	Remove and replace second pair of overshoes when exiting the pit to reduce risk of spreading contamination.	OK
Prep	Check tools: <ul style="list-style-type: none"> ✓• Hex Keys (3/16" & 3/8") ✓• Side Cutter ✓• Wipes ✓• 10" Cable Ties ✓• RAM 		OK
Safety	Check with ISAC Ops re: alpha CAM reading ✓ P beam off for at least 30 min ✓ before entering target pit Check the General Field of ITW/ ITE	RAM or pole monitor ($\leq 500 \mu\text{Sv/h}$)	OK
0	High Active Cooling Water ✓	<ul style="list-style-type: none"> ✓• Verify valve for supply water closed ✓• Verify valve for return water closed 	OK
1	Shutter	<ul style="list-style-type: none"> • Cut cable tie 	✓

Target Module Connection and Disconnection Procedure		
Document-141576	Release No. 3	Release Date.: 2019-10-23

SEQ	ITEM	NOTE	CHECK
		• Push down bellow (air cylinder)	✓ OK
2	Compressed Air to Shutter and Valves (x2) ✓	Shutter should be opened (pushed down)	✓ OK
3	Gas Line (5/8" & 11/16")	FEBIAD target only Two manual valves are opened	N/A
4	ITW/ITE Roughing out	Ask ISAC operator rouging out ITW/ITE	
5	High Current Cables: <ul style="list-style-type: none"> a) (A)Target Oven + b) (B)Target Oven - c) (C)Tube heater - d) (D)Tube Heater + e) (T)60KV Bias ✓ f) (PQ)Coil + ✓ g) (RU)Coil - 	f) FEBIAD target only g) FEBIAD target only	OK
6	Extraction Electrode (I) ✓		OK
7	Two 6-pin connectors (T,H) x2	Connect grounding wires to 60 kv bias	OK
8	Einzel Lens (Y) ✓	Einzel lens cable should be routed as far away from all 60 kV corona rings as possible	OK
9	52 Pin Connector (H)	Ground to bias stand	N/A
10	<ul style="list-style-type: none"> a) Water Lines <ul style="list-style-type: none"> ✓ 1. Target Oven ✓ 2. Tube Heater ✓ 3. MSP ✓ 4. EE ✓ 5. HS ✓ 6. Window ✓ 7. Coil 1 ✓ b) No Drip Leaks on Quick Connector (QC) ✓ c) No contact between SST Elbows and QC 	<ul style="list-style-type: none"> a) Water Lines <ol style="list-style-type: none"> 1. With <u>bypass loop</u> between Ta+ and Ta- on module 2. With <u>bypass loop</u> between Tu+ and Tu- on module 3. Bypassed (looped) on station. Cable tie to station. <i>for coils</i> 4. Connected to module always b) Open suppl and return valves <ul style="list-style-type: none"> ✓ 1. Hand check, wipe away water if necessary ✓ 2. SST elbows and quick connectors must be clear of each other, otherwise an electrical short will be produced. 	OK


Target Module Connection and Disconnection Procedure		
Document-141576	Release No. 3	Release Date.: 2019-10-23

SEQ	ITEM	NOTE	CHECK
11	Vacuum System <input checked="" type="checkbox"/> a) TP1 Controller <input checked="" type="checkbox"/> b) TP2 Controller <input checked="" type="checkbox"/> c) TP1 BV1 <input checked="" type="checkbox"/> d) TP2 BV2 <input checked="" type="checkbox"/> e) IG1 <input checked="" type="checkbox"/> f) TP1 TP2 Fans	a) Connector on pump body b) Connector on pump body c) KF 25 and O-ring, Connector for BV 24 V DC d) KF 25 and O-ring, Connector for BV 24 V DC e) Align the gauge pins f) Attach and switch on all fans (2 of 110 V Plugs for ITW, switch on Extension bar for ITE)	OK <input checked="" type="checkbox"/>
12	Steers <input checked="" type="checkbox"/> ITE: <input checked="" type="checkbox"/> • Top <input checked="" type="checkbox"/> • Left <input checked="" type="checkbox"/> • Bottom (right) ITW: <input type="checkbox"/> • X <input type="checkbox"/> • Y <input type="checkbox"/> • Common <i>Handwritten notes: TOP, TOP OK, OL, BOTTOM, TM2</i>	ITE-TM2: <ul style="list-style-type: none"> • Top-X • Left-Y • Bottom (right) – Common ITW – TM4: <ul style="list-style-type: none"> • X-Top • Y-Left • Common – Bottom (Right) 	OK
13	ISAC Control Page set up (plug, connector)	Surface with ERZEL LENS, IGLIS, and FEBIAD	OK
14	TP1 TP2 Controllers Reset	Electrical room, TP1 and TP2 controllers	OK
15	Water Signals Check <input checked="" type="checkbox"/> a) Target Module: <input checked="" type="checkbox"/> 1. Target, <input checked="" type="checkbox"/> 2. Tube, <input checked="" type="checkbox"/> 3. MSP <input checked="" type="checkbox"/> 4. HS <input checked="" type="checkbox"/> 5. EE <input checked="" type="checkbox"/> 6. Coil (1) <input checked="" type="checkbox"/> 7. Module Window <input checked="" type="checkbox"/> b) Beamline 2A: <input checked="" type="checkbox"/> 1. Tank <input checked="" type="checkbox"/> 2. Dump (Plug) <input checked="" type="checkbox"/> 3. Dump Shielding <input checked="" type="checkbox"/> 4. 2A Window <input checked="" type="checkbox"/> 5. Collimator	In Electrical room, water signal panels: Yellow lights should flick at certain frequency and green lights should be constantly on *If signal is not right, go back to pit and visually check wheel spin in flow sensor for trouble shooting TM2 and TM4 GE line are not in use (leak), No signal	OK
16	Double Check Module Connection	General, visually check all connections Verify voltage gaps free of cables and waterlines	

Target Module Connection and Disconnection Procedure		
Document-141576	Release No. 3	Release Date.: 2019-10-23

SEQ	ITEM	NOTE	CHECK
17	HV Fence and HV Cover on TM Service Cap ✓	Limit switches and cables Retract HV Keys	OK
18	Restore HV Keys to Electrical Room ✓	Limit switches signals check in electrical room	OK
19	Start TP1 TP2 ✓	ITW/ITE: CG4/CG4S below 200 mTorr (ask ISAC OP)	OK
20	All Turbo Pumps(six) Current Draw Check at Normal Status ✓	Check current draw for each pump on TP controller, current draw at full speed (38kRPM) ≤ 2.0 A Visually confirm TPBVs in pit are opened (red buttons stick out)	✓
21	Return Work Permit and E-log entry		

NOTES:

DATE: 2020-03-18
 TARGET: P2W TEST
 TARGET MODULE: TM1 TM2 TM3 TM4
 STATION: ITW ITE
 SIGNATURE 1: 
 SIGNATURE 2: 